

### EXPERIMENT REPORT

Experiment Name	Linear Applications of Operational Amplifiers
Lab Assistant	Berat DOĞAN
Author of the Report (Name / No / Department)	Tuğrul YATAĞAN 040100117 Computer Engineering
Group Number and Experiment Date	D27 15.11.2013


Report Score	<b>Deliver Date</b>	Receive Date
	22.11.2013	

### Aim of the Experiment

In this experiment session, we investigate basic understanding of operational amplifiers (op-amps) for performing linear applications such as inverting amplifiers, non-inverting amplifiers and some mathematical functions.

#### **Exp #1 Inverting OP-AMP**

We provide 2V peak to peak sinusoidal wave signal to input. R1 is  $10k\ \Omega$  resistor and R2 is a  $100k\ \Omega$  linear potentiometer. Since R2 is potentiometer, we can set various values for R2 and measure the peak to peak voltage of output signal from oscilloscope.




 $V_{in} = 2V (V_{pp})$ 

$\mathbf{R}_2(\Omega)$	Measured V <sub>out</sub> (V <sub>pp</sub> )	Theoretical V <sub>out</sub> (V <sub>pp</sub> )
100k	18.4 V	20 V
75k	14.4 V	15 V
50k	9.46 V	10 V
25k	2.54 V	5 V
10k	2 V	2 V

Theoretical  $V_{\text{out}}$  calculated from the voltage gain equation of the inverting amplifier circuit is:


$$\frac{V_{out}}{V_{in}} = -\frac{R_2}{R_1}$$



As can be seen in simulation oscilloscope screen, input signal (yellow line) is amplified and inverted to output signal (blue line).

### **Exp #2 Non-Inverting OP-AMP**

We provide 2V peak to peak sinusoidal wave signal to input like first experiment. R1 is  $10k\ \Omega$  resistor and R2 is a  $100k\ \Omega$  linear potentiometer. Since R2 is potentiometer, we can set various values for R2 and measure the peak to peak voltage of output signal from oscilloscope.




$$V_{in} = 2V (V_{pp})$$

$\mathbf{R}_2(\Omega)$	Measured V <sub>out</sub> (V <sub>pp</sub> )	Theoretical V <sub>out</sub> (V <sub>pp</sub> )
100k	20.2 V	22 V
75k	16.6 V	17 V
50k	11.9 V	12 V
25k	6.91 V	7 V
10k	3.95 V	4 V

Theoretical  $V_{out}$  calculated from the voltage gain equation of the non-inverting amplifier circuit is:

$$\frac{V_{out}}{V_{in}} = 1 + \frac{R_2}{R_1}$$



As can be seen in simulation oscilloscope screen, input signal (yellow line) is amplified and to output signal (blue line).

### **Exp #3 Summing Amplifier**

We provide 5V DC signal as  $V_1$  and 6V peak to peak sinusoidal wave signal as  $V_2$  to input. R1 is  $8.2k\Omega$  resistor, R2 is  $2.7k\Omega$  resistor and R3 is  $8.2k\Omega$  resistor for adjusting a=1 and b=3 in output equation;


$$V_0 = -(aV_1 + bV_2)$$
 so;


$$V_o = -(V_1 + 3V_2)$$

Which is actually; the voltage gain equation of the summing amplifier:

$$V_o = -\left(\frac{R_3}{R_1}V_1 + \frac{R_3}{R_2}V_2\right)$$

Then we measure the peak to peak voltage of output signal from oscilloscope.







As can be seen in simulation oscilloscope screen; input signal 5V DC as  $V_1$  (yellow line), input signal 6V sinusoidal as  $V_2$  (blue line), ground (green line) and the output signal (purple line). Output is like inverted and amplified sinusoidal wave with 5V offset bellow the ground.

### **Exp #4 OP-AMP Integrator**

We provide 5V peak to peak square wave signal as  $V_{in}$ , R1 is  $10k\Omega$  resistor, R2 is  $100k\Omega$  resistor and  $R_{eq}$  is  $10k\Omega$  resistor for adjusting voltage equation of the op-amp integrator.

$$V_o = -\frac{1}{RC} \int V_1 dt + V_{o(t=0)}$$





As can be seen in simulation oscilloscope screen; input signal 5V square wave as  $V_{in}$  (yellow line) and the output signal (blue line). Output is integral form of input signal, so integral form of square wave signal is rectangle wave signal.